



INSTRUCTIONS

Unpacking the MBx10 from the shipping carton.

STEPS

1. Open top of box
2. Cut down one corner of the box so you can peel the sides of the box away from the metal frame.
3. Clip or unwind the four **DOUBLE** wires holding top of metal frame to bottom of frame to unhook top from bottom.
4. Pull wires off of frame and discard to get them out of the way.
5. Remove the two bolts holding front fork to frame.
6. Pull angle iron frame straight up, away from bottom frame.
7. Bike should be easily removable now.
8. Refer to page 17 of Owners Manual for initial setup procedures, including how to attach the handlebars.

